


EN

DUOS mini

Heated Tobacco
360° Heating
Device
User Manual



ONE STICK, TWO ACT.

Dear User,
Thank you for purchasing
our product. For your better
experience of the product,
please read all instructions
carefully and use it as a
guide.

● Package contents

Heating Device×1
User Manual ×1
Self-stick Slide Caps × 2

● Product overview

Front of Cap :




Stick Port Cap

Back of Cap :



Double-Sided Adhesive Tape
(Remove Before Use)




Power
button

LED
screen



Type-C
port

● LED screen indication



● Specification

Product name.....DUOS mini
Size.....22.9×30.8×100.9 mm
Weight.....approximately 73.6 g
Battery.....3.7V / 2600mAh
Input.....5V / 2A
Preheating.....30s
Heating.....240s / times
Session.....~30 sessions
Charging time.....~150 min

● Product lock/unlock

1. Press the power button 5 times to lock / unlock the product.
2. To ensure transportation safety, the product will be in child lock mode when it leaves the factory. Please unlock it before use.
3. To ensure safety of cleaning incase, please lock the product before cleaning.



User mode
(CO/HO)



Lock mode



● Heating mode switch

1. The system sensor will detect the temperature automatically to select the heating mode for the better heating session.
2. COLD mode (CO) means the product is in room temperature, can offer a stronger preheating session
3. HOT mode (HO) means the product is still in a high temperature after use, it will use another setting to preheating the stick, to prevent overheated.
4. When it is in "HOT" mode, cool it down in room temperature around 10 min, it will switch to "COLD" mode automatically.

COLD mode
(CO)



HOT mode
(HO)




● Inserting the stick

1. Before use, the device must be in user mode. Insert the consumable stick into the slot until it is firmly in place.




● Preheating

1. Press and hold the power button for 1.5 seconds, the device will vibrate to start preheating. Then the icon will start to illuminate, indicating the preheating countdown.
2. The preheating digit will countdown from 30s, until it reaches 0, the device will vibrate again, indicating that preheating is completed and can start to puff.



● Puffing

1. During heating session, the screen will display the number of remaining time countdown, 240s for every puffing sessions.
2. When there are 30 seconds remained, the device will vibrate and the icon will start to flash, indicating that the puff time is about to end.
3. The device will turn off when timer digits reaches 0, or press the power button for 1.5 seconds.
4. Repeat "Preheating & Puffing" step for the SECOND ENJOYMENT of 1 stick. 1 new stick can be used for 240s x 2 heating sessions.



● Removing the stick

1. After fully use, the device will turn off, pull out the stick from the slot.
2. Or whenever you need to switch off the device, press the power button for 1.5s.




● Charging

1. Plug the USB Type-C cable into the port at the bottom of the device to start charging.
2. During charging, the battery icon at the bottom of the screen will dynamically change based on the current battery level.
3. When the battery is fully charged, the battery icon will turn off.



USB Type-C 5V/2A



*when it flashes,
it needs to be charge

● Troubleshooting

1. Brand icon in RED.
----Product malfunction. Please contact the retailer.
2. Brand icon flashes in RED.
----High temperature warning. Put the device aside in room temperature for 10 mins to cool down.
3. Battery icon no response
----Charging failure. Change the charging cable or adapter to 5V/2A.
4. Battery icon has 1 bar left
----Charge the device immediately.

● Safety cautions

- DO NOT disassemble or assemble this device except as directed in this user guide.
- Ensure that no dust, lint, or debris, enter the device, as this may cause personal injury.
- DO NOT drop or hit the device to prevent damage from strong impact.
- DO NOT attempt to touch the heating element under any circumstances, as this may cause personal injury or damage to the product.
- DO NOT insert any objects other than the consumable sticks into the heating chamber.
- DO NOT store or use this device in the presence of flammable or explosive substances, liquids, or gases.
- DO NOT store or use this device in excessive heat or humid environments. (store it between -10 to 45 °C)

DO NOT immerse this device in water or allow it to get wet. If this happens during charging, stop charging immediately to ensure safety.

Charge this device by using a 5V/2A adapter that as safety standards.

This device contains a non-replaceable battery.

This device uses a lithium-ion battery. When discarding, please follow the local government regulations for the classification and management of electrical and electronic products and lithium-ion batteries.

The consumable sticks compatible to this device are not designed for multiple re-use and should not be ignited with open flames.

This device is compatible to certain heated tobacco consumable sticks.

Do not use this device with traditional cigarettes, or similar products, or other tobacco products not approved by the manufacturer.

This device is a clean-free product. To ensure long-term operation, it is recommended to gently remove any residue by using a cotton swab.

Keep this device and its components out of the reach of children or pets.

Please read the instructions in this document carefully and use this product properly.


These instructions do not cover all situations. Follow the instructions when using and maintaining the device. To ensure safely use, please read this user manual carefully.

After reading, please keep this user manual in a safe place.

JP

DUOS
mini加熱式タバコ
専用デバイス

取扱説明書



ONE STICK, TWO ACT.

この度は、本製品をご購入いただき、誠にありがとうございます。より快適にご使用いただくために、まず取扱説明書をよくお読みいただき、記載の内容に従ってご使用ください。


● セット内容

本体×1


取扱説明書×1

貼り付け式スライド
キャップ×2

● 各部の名前



● LEDスクリーン表示





● 仕様

製品：.....DUOS mini
サイズ.....22.9×30.8×100.9 mm
重量：.....約73.6 g
バッテリー：.....3.7V / 2600mAh
入力：.....5V / 2A
予熱時間：.....30秒
喫煙時間：.....240秒/回
加熱回数：.....約30回
充電時間：.....約150分


● ロック/ロック解除

- 電源ボタンを5回連続で押すと、ロック/ロック解除します。
- 安全な持ち運びのため、工場出荷時にはチャイルドロックモードが設定されています。ご使用前にロックを解除してください。
- 清掃時の安全を確保するために、清掃前に製品をロックしてください。

ユーザー
モード
(CO/HO)ロック
モード

● 加熱モードスイッチ

- システムセンサーは温度を自動的に検出し、適切な加熱モードを選択することで、より良い加熱を実現します。
- コールドモード (CO) は製品が常温であることを表し、より強い予熱効果が提供できます。
- ホットモード (HO) は製品が使用後にまだ高温状態になっていることを示し、過熱を防ぐために最適な温度設定でスティックを予熱します。
- デバイスを10分間静置して冷却すると、自動的にコールドモード (CO) に切り替わります。


コールド
モード
(CO)ホット
モード
(HO)

● スティック差し込み

- ご使用前に、デバイスをユーザーモードにしてください。スティックを差し込み口にしっかりと固定されるまで挿入してください。


● 予熱

- 電源ボタンを1.5秒間長押しすると、デバイスが振動して予熱を開始します。その後、アイコンが点灯し、予熱カウントダウンを示します。
- 予熱カウントダウンは30秒から始まり、カウントダウン終了 (つまり0) まで続きます。デバイスが再び振動し、予熱が完了したことを知らせ、吸引が開始できます。



● 喫煙 (1回目と2回目)

- 加熱中に、画面に残り時間のカウントダウンが表示され、各加熱時間は240秒です。
- 残り30秒になると、デバイスが振動し、アイコンが点滅し始め、喫煙時間が終了することを示します。
- タイマーが0になるとデバイスの電源がオフになります。または、電源ボタンを1.5秒間押し続けた後もデバイスの電源がオフになります。
- 「予熱と喫煙」の手順を繰り返して、もう1本スティックをお楽しみください。1本で240秒×2回が吸えます。




● スティック取り外し

- 使用后、スティックを差し込み口から取り外し、製品の電源を必ず切ってください。
- または、デバイスの電源を切る必要があります。または、電源ボタンを1.5秒間押します。

● 充電

- USB Type-Cケーブルをデバイスの底部のポートに差し込むと、充電が開始されます。
- 充電時に、画面下部のバッテリーアイコンは現在のバッテリー残量に応じて動的に変化します。
- バッテリーが完全に充電されると、バッテリーアイコンはオフになります。



● 故障対処

- 赤色アイコンが点灯する。
----製品故障。製品に不具合があった場合、販売店にお問い合わせください。
- 赤色アイコンが点滅する。
----高温警告。約10分間冷却してからご使用ください。
- バッテリーアイコンが表示されない。
----充電不可。充電器または充電ケーブルを交換してください。
- インジケーターが1点のみ点灯している
----バッテリー残量低下。充電してください。

● 安全上のご注意

この取扱説明書には特に記載がない限り、このデバイスを取り外したり組み立てたりしないでください。

人身傷害の恐れがあるので、ほこり、絨毛、または破片がデバイス内に入らないようにしてください。

強い衝撃を受けて破損しないように、機器を落としたりぶついたりしないでください。

いずれの場合も加熱部分に触れようとしないでください。人に危害を加えたり、製品を壊したりする恐れがあります。

加熱室内にスティック以外の物を入れないでください。

可燃性または爆発性の物質、液体、またはガスがある場所で、このデバイスを保管したり使用したりしないでください。ご注意ください。

本製品を極端に高温または多湿な環境で保管または使用しないでください。(保管温度は-10~45°Cです)

本製品を水に浸したり、濡らしたりしないでください。充電中に水に浸かたり、濡らしたりした場合は、安全のために直ちに充電を中止してください。

安全基準を満たした5V/2Aアダプタを使用して、本デバイスを充電してください。

本製品には交換不可能なバッテリーが内蔵されています。

本製品はリチウムイオン電池を使用しています。廃棄する場合は、電気電子製品とリチウムイオン電池の分類管理に関する各自自治体の規定を遵守してください。

本デバイスと互換性のある消耗スティックは、数回の繰り返し使用のために設計されているわけではなく、火を使って点火するべきではありません。

本製品は従来のタバコ、類似製品、またはメーカーの承認を得ていない他のタバコ製品と一緒に使用しないでください。

本製品は清掃の必要はありません。長期使用を確保するためには、綿棒で優しく拭き取っていただくことをお勧めします。

本製品とそのコンポーネントは、お子様やペットの手の届かない場所に設置してください。

本取扱説明書をよくお読みいただき、本製品を正しく使用してください。

これらの安全上の注意事項は全て状況に対応しているわけではありません。製品の使用及びメンテナンスには十分ご注意ください。

本製品を極端に高温または多湿な環境で保管または使用しないでください。(保管温度は-10~45°Cです)

ご一読の上、本取扱説明書は大切に保管してくださいませようお願い致します。