

JP

DUOS prime



加熱式タバコ
専用デバイス

取扱説明書


ONE STICK, TWO ACT.

この度は、本製品をご購入いただき、誠にありがとうございます。より快適にご利用いただくために、まず取扱説明書をよくお読みいただき、記載の内容に従ってご使用ください。

セット内容

本体×1
取扱説明書×1


各部の名前



仕様


製品名:.....DUOS prime
サイズ:.....21.7x33.5x104mm
重量:.....約90g
バッテリー:.....3.7V / 3300mAh
入力:.....5V / 2A
予熱時間:.....30秒
喫煙時間:.....
240秒/回(02 エコモード)
420秒/回(01 ロングモード)
加熱回数:.....
約34 回(02 エコモード)
約16 回(01 ロングモード)
充電時間:.....約180分

ロック/ロック解除



- 1.電源ボタンを5回連続で押すと、ロック/ロック解除します。
- 2.自動加熱機能が搭載しており、清掃時の安全を確保するために、清掃前に製品をロックしてください。

LEDスクリーン表示



加熱モードスイッチ

電源ボタンを3回連続で押すと、加熱モードを切り替えることができます。

お好みに合わせて、2種類の加熱モードから選択してください。




01
ロングモード (01) は
1回420秒の喫煙時間
で、スティックを最後
までじっくり楽しめる
モードです。



02
エコモード(02)は1回
240秒の喫煙時間
で、スティックを2回
に分けて効率的に楽
しめるモードです。


※デフォルト設定はエコモード (02) です。

STEP1:スティック差し込み




ご使用前に、デバイスをユーザーモードにしてください。キャップをスライドして開けます。スティックを差し込み口にしっかりと固定されるまで挿入してください。

STEP2:予熱





スティックを挿入すると、自動で予熱を開始します。または、電源ボタンを1.5秒間長押しして予熱を開始することもできます。予熱開始時にデバイスが振動します。その後、アイコンが点灯し、予熱カウントダウンを示します。



予熱カウントダウンは30秒から始まり、カウントダウン終了 (つまり0) まで続きます。デバイスが再び振動し、予熱が完了したことを知らせ、吸引が開始できます。

STEP3:喫煙時間



タイマーが 0 になるとデバイスの電源がオフになります。または、電源ボタンを1.5 秒間押し続けた後もデバイスの電源がオフになります。

1台で2回吸える (02エコモード)

「予熱と喫煙」の手順を繰り返して、もう1回スティックをお楽しみください。1本で240秒x2回が吸えます。

スティック取り出し

1.420秒/240秒の使用時間が終了すると、デバイスの電源は自動的にオフになります。スティックを取り出してください。


2.途中停止機能: 喫煙途中でスティックを抜き出すか、電源ボタンを1.5秒間長押しすると、加熱が中止され、電源がオフになります。

3.使用後はキャップをスライドして閉じてください。ほこりや異物がデバイス内部に入らないようにしてください。

充電



USB Type-Cケーブルをデバイスの底部のポートに差し込むと、充電が開始されます。



充電時に、画面下部のバッテリーアイコンは現在のバッテリー残量に応じて動的に変化します。



バッテリーが完全に充電されると、バッテリーアイコンはオフになります。

5V/2A入力時: 約180分 (トリクル充電時間を含む)

故障対処

1. 赤色アイコンが点灯する
----製品故障。製品に不具合があった場合、販売店にお問い合わせください。
2. 赤色アイコンが点滅する
----高温警告。約10分間冷却してからご使用ください。
3. バッテリーアイコンが表示されない
----充電不可。充電器または充電ケーブルを交換してください。
4. インジケーターが1点のみ点灯している
----バッテリー残量低下。充電してください。

安全上のご注意

- ・この取扱説明書には特に記載がない限り、このデバイスを取り外したり組み立てたりしないでください。
- ・人身傷害の恐れがあるので、ほこり、絨毛、または破片がデバイス内に入らないようにしてください。
- ・強い衝撃を受けて破損しないように、機器を落としたりぶつけたりしないでください。
- ・いずれの場合も加熱部分に触れようとしないでください。人に危害を加えたり、製品を壊したりする恐れがあります。
- ・加熱部にスティック以外の物を入れないでください。

- ・可燃性または爆発性の物質、液体、またはガスがある場所で、このデバイスを保管したり使用したりしないでください。
- ・本製品を極端に高温または多湿な環境で保管または使用しないでください。(保管温度は-10~45°Cです)
- ・本製品を水に浸したり、濡らしたりしないでください。充電中に水に浸かたり、濡らしたりした場合は、安全のために直ちに充電を中止してください。

- ・安全基準を満たした5V/2Aアダプタを使用して、本デバイスを充電してください。
- ・本デバイスには交換不可能なバッテリーが内蔵されています。

- ・本製品はリチウムイオン電池を使用しています。廃棄する場合は、電気電子製品とリチウムイオン電池の分類管理に関する各自自治体の規定を遵守してください。

- ・本デバイスと互換性のある消耗スティックは、数回の繰り返し使用のために設計されているわけではなく、火を使って点火するべきではありません。

- ・本デバイスはいくつかの加熱式タバコ製品と互換性があります。
- ・本デバイスを従来のタバコ、類似製品、またはメーカーの承認を得ていない他のタバコ製品と一緒に使用しないでください。

- ・本製品は清掃の必要はありません。長期使用を確保するためには、綿棒で優しく拭き取っていただくことをお勧めします。

- ・本製品とそのコンポーネントは、お子様やペットの手の届かない場所に設置してください。


- ・本取扱説明書をよくお読みいただき、本製品を正しく使用してください。

- ・これらの安全上の注意事項は全ての状況に対応しているわけではありません。製品の使用及びメンテナンスには十分ご注意ください。

POWERED BY
BESMO

EN

DUOS prime

Heated Tobacco
Device User Manual


ONE STICK, TWO ACT.

Dear User,


Thank you for purchasing our product. For your better experience of the product, please read all instructions carefully and use it as a guide.

Package contents


Heating Device×1
User Manual ×1

Product overview**Specification**


Product name.....DUOS prime
Size.....21.7x33.5x104mm
Weight.....90 g
Battery.....3.7V / 3300mAh
Input.....5V / 2A
Preheating.....30 s
Heating
01: 420 seconds/session
02: 240 seconds/session
Session
01: Approximately 16 times
02: Approximately 34 times
Charging time.....~180 min

Product lock/unlock


1. Press the power button 5 times to lock / unlock the product.
2. This device features Auto Start. To ensure safety of cleaning incase, please lock the product before cleaning.

LED screen indication**Heating mode switch**


• Press the power button three times consecutively to switch between heating modes. Choose from two heating modes according to your preference.




※ The default setting is Eco Mode (02).

STEP1: Inserting the stick

Before use, the device must be in user mode and open the slider cover. Insert the consumable stick into the slot until it is firmly in place.

STEP2 : Preheating

When inserting the consumable stick, or press and hold the button for 1.5 seconds, the device will vibrate automatically. Then the icon will start to illuminate, indicating the preheating countdown.



The preheating digit will countdown from 30s, until it reaches 0, the device will vibrate again, indicating that preheating is complete and you can start to puff.

STEP3 : Puffing

During heating session, the screen will display the number of remaining time countdown, 240 seconds for every puffing sessions.




When there are 30 seconds remained, the device will vibrate and the icon will start to flash, indicating that the puff time is about to end.

The device will turn off when timer digits reaches 0, or press the power button for 15 seconds.

- Enjoy two sessions with one device (02 Eco Mode)
- Repeat the "Preheating and Smoking" procedure to enjoy the stick for another session. One stick can be enjoyed for two 240-second sessions.

Removing the stick

1. After fully use, the device will turn off, pull out the stick from the slot.
2. Or whenever you need to switch off the device, pull out the stick or press the power button for 1.5s.
3. Close the slider cover after use to prevent dust and foreign objects from entering the device.

Charging

During charging, the battery icon at the bottom of the screen will dynamically change based on the current battery level.

When the battery is fully charged, the battery icon will turn off.

Charging time is approximately 150 minutes with a 5V/2A power adapter, including trickle charging.

Troubleshooting

1. Brand icon in RED.
—Product malfunction.
Please contact the retailer.
2. Brand icon flashes in RED.
—High temperature warning. Put the device aside for 10 mins to cool down.
3. Battery icon no response.
—Charging failure. Change the charging cable or adapter to 5V/2A.
4. Battery icon has 1 bar left.
—Charge the device immediately.

Safety cautions

- DO NOT disassemble or assemble this device except as directed in this user guide.
- Ensure that no dust, lint, or debris, enter the device, as this may cause personal injury.
- DO NOT drop or hit the device to prevent damage from strong impact.
- DO NOT attempt to touch the heating element under any circumstances, as this may cause personal injury or damage to the product.
- DO NOT insert any objects other than the consumable sticks into the heating chamber.

- DO NOT store or use this device in the presence of flammable or explosive substances, liquids, or gases.
- DO NOT store or use this device in excessive heat or humid environments. (store it between -10 to 45 °C)
- DO NOT immerse this device in water or allow it to get wet. If this happens during charging, stop charging immediately to ensure safety.

- Charge this device by using a 5V/2A adapter that as safety standards.

- This device contains a non-replaceable battery.

- This device uses a lithium-ion battery. When discarding, please follow the local government regulations for the classification and management of electrical and electronic products and lithium-ion batteries.

- The consumable sticks compatible with this device are not designed for multiple re-use and should not be ignited with open flames.

- This device is compatible to certain heated tobacco consumable sticks.

- Do not use this device with traditional cigarettes, or similar products, or other tobacco products not approved by the manufacturer.

- This device is a clean-free product. To ensure long-term operation, it is recommended to gently remove any residue by using a cotton swab.

- Keep this device and its components out of the reach of children or pets.

- Please read the instructions in this document carefully and use this product properly.

- These instructions and instructions do not cover all situations. Follow the instructions when using and maintaining the device. To ensure safe use, please read this user manual carefully.

- After reading, please keep this user manual in a safe place.

POWERED BY
BESMO